



Installation and Setup Guide

Clavister SG4200 Series

Clavister AB
Torggatan 10
SE-891 33 Örnsköldsvik
SWEDEN

Phone: +46-660-299200
Fax: +46-660-12250

www.clavister.com

Build: 890
Published 2008-06-19
Copyright © 2008 Clavister AB

Installation and Setup Guide

Clavister SG4200 Series

Published 2008-06-19
Build: 890

Copyright © 2008 Clavister AB

Copyright Notice

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without written consent of the author.

Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

Limitations of Liability

UNDER NO CIRCUMSTANCES SHALL CLAVISTER OR ITS SUPPLIERS BE LIABLE FOR DAMAGES OF ANY CHARACTER (E.G. DAMAGES FOR LOSS OF PROFIT, SOFTWARE RESTORATION, WORK STOPPAGE, LOSS OF SAVED DATA OR ANY OTHER COMMERCIAL DAMAGES OR LOSSES) RESULTING FROM THE APPLICATION OR IMPROPER USE OF THE CLAVISTER PRODUCT OR FAILURE OF THE PRODUCT, EVEN IF CLAVISTER IS INFORMED OF THE POSSIBILITY OF SUCH DAMAGES. FURTHERMORE, CLAVISTER WILL NOT BE LIABLE FOR THIRD-PARTY CLAIMS AGAINST CUSTOMER FOR LOSSES OR DAMAGES. CLAVISTER WILL IN NO EVENT BE LIABLE FOR ANY DAMAGES IN EXCESS OF THE AMOUNT CLAVISTER RECEIVED FROM THE END-USER FOR THE PRODUCT.

Table of Contents

Preface	5
1. Product Overview	6
1.1. Unpacking the Product	6
1.2. Keypad, Ports and Connectors	7
2. Installation	9
2.1. Installation Guidelines	9
2.2. Installing SFP modules	11
2.3. Connecting Power	13
3. Initial Setup	16
3.1. Attaching Connectors	16
3.1.1. Connecting to a Network	16
3.1.2. Connecting the Console Port	16
3.2. Local RS232 Console Setup	18
3.3. Setup with Display and Keypad	20
3.4. Finalizing the Configuration	21
4. Product Maintenance	23
4.1. Replacing the Power Supply	23
4.2. Replacing Fan Modules	25
5. Warranty	27
6. Safety	29
7. Hardware Specifications	32

List of Figures

1.1.	7
2.1. A typical 1000 Base LX/SX module	11
2.2. Installing a 1000 Base LX/SX module	11
2.3. A typical 1000 Base TX module	11
2.4. Installing a 1000 Base TX module	12
2.5. Side view of the Clavister SG4200 Series showing multiple cable connections.	12
2.6. SG3200 Rear View	13
2.7. Rear view of the Clavister SG4200 Series.	13
3.1. A Typical SG4200 Series Installation Setup	16
4.1. Replaceable modules in an SG4200 Series device.	23
4.2. Replacing a SG4200 Series power supply.	24
4.3. An SG4200 Series AC power supply unit.	24
4.4. An SG4200 Series DC power supply unit.	24
4.5. An SG4200 Series fan module.	25
4.6. Clavister SG4200 Series fan disassembly.	25
7.1. SG4200 Series Dimensions and Weight	32
7.2. Regulatory and Safety Standards	32
7.3. Environmental	32
7.4. Power Specifications	32

Preface

Target Audience

The target audience for this guide is the user who has taken delivery of a packaged Clavister SG4200 Series appliance. The guide takes the user from unpacking and installation of the device through to power-up and initial network connection.

Text Structure

The text is divided into chapters and subsections. Numbered subsections are shown in the table of contents at the beginning of the document.

Text links

Where a "See section" link is provided in the main text, this can be clicked on to take the reader directly to that reference eg. see Chapter 7, *Hardware Specifications*.

Web links

Web links included in the document are clickable eg. <http://www.clavister.com>

Notes to the main text

Special sections of text which the reader should pay special attention to are indicated by icons on the left hand side of the page followed by a short paragraph in italicized text. There are the following types of such sections:



Note

This indicates some piece of information that is an addition to the preceding text. It may concern something that is being emphasised or something that is not obvious or explicitly stated in the preceding text.



Tip

This indicates a piece of non-critical information that is useful to know in certain situations but is not essential reading.



Caution

This indicates where the reader should be careful with their actions as an undesirable situation may result if care is not exercised.



Important

This is an essential point that the reader should read and understand.



Warning

This is essential reading for the user as they should be aware that a serious situation may result if certain actions are taken or not taken.

Chapter 1. Product Overview

- Unpacking the Product, page 6
- Keypad, Ports and Connectors, page 7

1.1. Unpacking the Product



This section details the unpacking of the SG4200 Series appliance. Open the packaging box used for shipping and carefully unpack the contents. The box should contain the following:

1. The Clavister SG4200 Series Appliance.
2. A mounting kit for 19" racks including rear mounting brackets. The side brackets for this kit are already be attached but can be removed for flat surface operation.
3. Attachable rubber feet for flat-surface mounting.
4. 1 x Ethernet cable.
5. DB9 female to RJ45 console cable for RS232 connection.
6. Power cord.
7. CD-ROM containing:
 - Clavister FineTune software.
 - Clavister Logger software.
 - Product documentation in PDF format.
8. Certificate of Authenticity



Note

If any items are missing from your package, please contact your reseller or distributor. All PDF documentation can be freely downloaded from the Clavister website.

1.2. Keypad, Ports and Connectors

This section is an overview of the hardware's external design and construction.

Figure 1.1.



The SG4200 Series features a number of connection ports. On the far right is the RS232 console port. On the far left is the device's display and keypad. Between are an array of 14 Ethernet ports.

Each Ethernet port has equal operational capacity and corresponds to a logical interface in the CorePlus software configuration. Going from left to right the Ethernet ports are:

1. 8 x Small Form Pluggable (SFP) Ethernet ports with logical interface names **sfp1** to **sfp8**. These are for Gigabit Ethernet links only.
2. 2 x RJ45 Gigabit Ethernet ports with logical interface names **ge1** and **ge2**. These connections are capable of link speed auto-negotiation and can therefore operate with 10Base-T, 100Base-Tx, or 1000Base-T.
3. 4 x RJ45 Fast Ethernet ports with logical interface names **fe1** to **fe4**. These connections are also capable of link speed auto-negotiation and can operate with 10Base-T or 100Base-Tx.

Port Status LEDs

On the SG4200 Series there are indicator lights associated with each port which illuminate according to link status and activity. The lights and lighting schemes vary according to port type:

SFP (sfp) ports

One green light is located directly to the right of the port connection. This is illuminated to show that a link is established.

Gigabit (ge) ports

Two lights are located at the top-right and top-left of the port. The top-left flashes green to indicate data traffic. The top-right light is: not lit if the link is 10 Mb, green if 100 Mb, yellow if 1 Gb.

Fast Ethernet (fe) ports

Two lights are located at the top-right and top-left of the port. The top-right flashes green to indicate data traffic. During 10 Mb operation the top-left light is not lit. During 100 Mb operation the top-left light is continuously yellow to indicate the link is established.

Chapter 2. Installation

- Installation Guidelines, page 9
- Installing SFP modules, page 11
- Connecting Power, page 13

2.1. Installation Guidelines

Follow these guidelines when installing your Clavister SG4200 Series appliance:

- Make sure that the power source circuits are properly grounded, then use the power cord supplied with the appliance to connect it to the power source.
- If your installation requires a different power cord than the one supplied with the appliance, be sure to use a power cord displaying the mark of the safety agency that defines the regulations for power cords in your country. The mark is your assurance that the power cord can be used safely with the appliance.
- Ensure that the appliance does not overload the power circuits, wiring and over-current protection. To determine the possibility of overloading the supply circuits, add together the ampere ratings of all devices installed on the same circuit as the appliance and compare the total with the rating limit for the circuit. The maximum ampere ratings are usually printed on the devices near the AC power connectors.
- Do not install the appliance in an environment where the operating ambient temperature might exceed the specified operating range (see Chapter 7, *Hardware Specifications*).
- Make sure that airflow around the sides and back of the appliance is not restricted.



Note

Detailed information concerning power supply range, operating temperature range etc. can be found at the end of this publication in Chapter 7, Hardware Specifications.

Flat Surface Installation

The SG4200 Series device can be mounted on any appropriate stable, flat, level surface that can safely support the weight of the appliance and its attached cables.

The rubber feet supplied with the SG4200 Series unit should be attached to the underside of the device for operation on a flat surface. This protects both the surface and the device from external damage as well as allowing air to circulate underneath the device during operation.

The fitted side brackets for rack installation can be removed by unscrewing the retaining screws.



Caution

Please ensure there is adequate space around the unit for ventilation and access to operating switches and cable connectors. No other objects should be placed on top of the unit.

Rack Installation

A rack mounted Clavister Security Gateway can be installed in most 19" standard racks. Fasten the appliance with screws suitable for the kind of rack you are using. The following guidelines should

be followed:

- A rack or cabinet used for mounting should be adequately secured to prevent it from becoming unstable and/or falling over.
- Devices installed in a rack or cabinet should be mounted as low as possible, with the heaviest devices at the bottom and progressively lighter devices installed above.



Note

SG4200 Series devices come with rack-mounting brackets already attached to the unit.

2.2. Installing SFP modules

Small Form Pluggable (SFP) modules come in different forms from different manufacturers. Shown below are some typical units. The SG4200 Series device does not come with SFP modules and these must be purchased separately.

Installation of SFP units is usually similar. With the units shown, the modules are inserted into sockets with the label facing upwards. The module slides gently into position by pressing inwards.

Figure 2.1. A typical 1000 Base LX/SX module




Figure 2.2. Installing a 1000 Base LX/SX module




Figure 2.3. A typical 1000 Base TX module



Figure 2.4. Installing a 1000 Base TX module



Figure 2.5. Side view of the Clavister SG4200 Series showing multiple cable connections.



2.3. Connecting Power

Figure 2.6. SG3200 Rear View

An SG4200 Series appliance is delivered in a form able to support AC or DC power, but not both. The device should be ordered in either an AC or DC compatible hardware version.



Important

Please read the advisory concerning electrical safety in Chapter 6, Safety.

The image below shows the back of the SG4200 Series. To the extreme right is the power cord socket. To the left of the socket is a recessed button for resetting the device to factory defaults.

Figure 2.7. Rear view of the Clavister SG4200 Series.



Connecting AC Power

To connect power, follow these steps:

1. Fit the power cord into the power adapter that comes with the SG4200 Series.
2. Plug the power adapters power plug into the power receptacle on the back panel of the SG4200 Series device.
3. Plug the other end of the power cord into a grounded power outlet.
4. After a console is connected as described in the following section, power on the appliance using the switch at the back of the unit.

Connecting DC Power

The DC power supply has single DC input supporting +/- 48VDC and return feed. A dedicated circuit breaker supporting the labelled current requirements is needed for the SG4200 Series

It is common that DC power is routed through DC power distribution panels in each rack in a typical site using battery backups providing 48 VDC. It might be located at the top of each rack where the SG4200 Series is to be installed. The SG4200 Series require a pair of cables connected to each set of terminal studs on the power distribution panel.



Note

Make sure to connect the input and return feed to the correct power distribution feed as there is no standard colouring scheme for DC power cables.

The device must be connected to earth ground during operation. Connect a cable to a earth ground from the cabinet or other suitable grounding point to the chassis by fastening a U-type lug to the end of the ground wire and fasten it to the chassis with the power supply retaining screw. Alternatively fasten it to the middle DC terminal labelled "FG".

**Warning**

The power feed ground and chassis ground must be connected to the same earth point at an installation site.

- Connect the device to earth ground:
 - Ensure a suitably qualified electrician has correctly installed the wiring.
 - Connect one end to the chassis ground point.
 - Connect the other end to the earth ground, for instance to the rack cabinet in which the SG4200 Series is installed.
- Connect cables to the power supply:
 - Be certain that the voltage from all DC power source cables is 0V before and during installation. Take precautions so that power cannot accidentally be restored during installation.
 - Ensure a suitably qualified electrician has correctly installed all power connections.
 - Loosen the screws on the power supply terminal block labeled "+" and "-".
 - Fasten the positive DC source power cable lug to the "+" terminal.
 - Fasten the negative DC source power cable lug to the "-" terminal.

The DC distribution panel should now be powered on and the following done:

- Measure voltage on the power supply terminal blocks and verify that 48VDC is properly provided.
- Set the power supply ON/OFF switch to its **ON** position.
- Verify startup.

**Protecting Against Power Surges**

It is strongly recommended that the purchase and use of a separate surge protection unit from a third party is considered to ensure that the hardware is protected from damage by electrical power surges. Surge protection is particularly important in locations subject to lightning strikes.

A surge protection unit should be installed exactly according to the manufacturer's instructions as correct installation of such units is vital for their effectiveness.

Chapter 3. Initial Setup

- Attaching Connectors, page 16
- Local RS232 Console Setup, page 18
- Setup with Display and Keypad, page 20
- Finalizing the Configuration, page 21

3.1. Attaching Connectors


3.1.1. Connecting to a Network

The initial configuration of the SG4200 Series device configures which Ethernet interface is to be used for remote management. Any interface can be used for this purpose. The selected interface can also be used for normal traffic.

The intended interface should be attached to the same network as the management server (or a network accessible from the management server via one or more routers).

Connect the interface to a switch or hub in the network using a regular straight-through Ethernet cable as illustrated below.

Figure 3.1. A Typical SG4200 Series Installation Setup



The SG4200 Series device can be connected directly to the network interface of the management workstation without using any switch or hub, but in that case a crossover cable is required.

The final phase of the initial set-up requires actions performed using either the SG4200 Series *Console* port or using the display and keypad on the front of the device (see Section 3.3, “Setup with Display and Keypad”).

3.1.2. Connecting the Console Port

The serial console port is an RS-232 port that enables a connection to a PC or terminal for monitoring and initial configuration of the SG4200 Series device. To use the console port, you need the following equipment:

- A terminal or a (portable) computer with a serial port and the ability to emulate a terminal i.e. using the Hyper Terminal software included in most Microsoft Windows installations). The terminal should have the following settings: **9600 baud, No parity, 8 bits, 1 stop bit and No**

Flow Control.

- An RS-232 cable with appropriate connectors. The SG4200 Series package includes an RS-232 null-modem cable.

To connect a terminal to the console port, follow these steps:

1. Set the terminal protocol as described previously.
2. Connect one of the connectors on the RS-232 cable supplied, directly to the console port on the SG4200 Series device.
3. Connect the other end of the cable to the terminal or the serial connector of the computer running the communications software.

3.2. Local RS232 Console Setup

Make sure that a terminal (or a computer running terminal emulation software such as Hyper-Terminal) is connected to the console port on the Clavister SG4200 Series hardware as described above in Section 3.1.2, “Connecting the Console Port”.

1. Having previously followed the instructions in Section 2.3, “Connecting Power”, the device should now be powered up.



Note

The hardware will require a short amount of time go through it's initial power up sequence and during this period there will be no output to the console.

When the appliance becomes operational, output similar to the following will appear on the console:

```
=====
Select Management Interface
=====
This will setup a small base configuration needed for the
system to start, and for remote management of the
Security Gateway to work. When this procedure is finished,
the remaining parts of the configuration may be completed
remotely using the Security Gateway Manager software.

Please choose your management interface
-----
ge1: Gigabit Ethernet interface 10/100/1000
ge2: Gigabit Ethernet interface 10/100/1000
fe1: Fast Ethernet interface 10/100
fe2: Fast Ethernet interface 10/100
fe3: Fast Ethernet interface 10/100
-----
ESC Return to previous menu
```

2. Select the interface that you have chosen for communication with the management station. Then press *Enter* to confirm your choice.
3. Enter the IP address you intend to use for the management interface and enter the appropriate netmask and default gateway. It is also possible to specify a remote management network if it is different from the local management interface subnet. Press Ctrl-S to save the settings and continue.

```
=====
Base IP configuration
=====
Management Interface:
fe1: Fast Ethernet interface 10/100

Use DHCP:          [ ]
Use PPPoE:         [ ]

IP Address:        [192.168.10 .10 ]
Netmask:           [255.255.255.0# ]
Gateway Address:   [ . . . ] (Leave blank for none)
Allowed Mgmt Net: [ . . . ] (Leave blank for local
network)
Netmask:           [ . . . ]

NOTE: If this interface is NOT the external interface,
the gateway address should normally be left blank.
-----
```

**Tip**

When entering IP addresses, use the "." (period) key to move the console cursor from one part of the IP address input field to the next.

The *Default Gateway* does not need to be specified if the management workstation is local. If, however, the management workstation is at least one router hop away from the appliance then the *Default Gateway* needs to be specified so that the appropriate entry is placed in the CorePlus routing table which is otherwise empty. Specifying the *Remote Management Net* is also required if the management workstation is not local.

**Note**

It is possible to use DHCP on the interface.

4. The following will appear in the terminal window:

```
=====  
Generating Base Configuration  
=====  
Writing configuration file, please wait...Done.  
It is recommended to start the core now.
```

Press **Y** to start CorePlus.

5. You will receive a confirmation message that CorePlus has successfully started as shown below:

```
Configuration done
```

3.3. Setup with Display and Keypad

The SG4200 Series appliance is equipped with a keypad and display on the front panel. These can be used to setup the base configuration. Alternatively a local console can be used as described in Section 3.2, “Local RS232 Console Setup”.

1. Power up the Clavister Security Gateway SG4200 Series appliance.

**Note**

The system will need some time to power up. During this time it will show the top row of the display filled with white blocks



```
Press Keypad to
Enter Setup
```

When the firmware has started the text *Press Keypad to Enter Setup* will appear. Press one of the buttons on the keypad to start the setup.

2. Select the interface that you would like to configure the base settings for by first pressing **Down** and then **Left** or **Right** until the correct interface name is shown.



```
Select Interface
< fcl >
```

When the correct interface is selected press **Up** to get back to the menu, i.e. the display should show **< Select Interface >**.

3. Now enter the IP address that is to be used for management purposes. To do this press **Left** until you get to the **< IP Address >** menu. Press **Down** once to get to the IP address configuration.



```
IP Address
^ 192.168.000.001 ^
```

Press **Left** or **Right** to move between the individual digits and **Up** or **Down** to change the value. When finished entering the IP address, move to either the left or rightmost part of the display (^) and press **Up** to get back to the menu. Now use **Left** to step to the **< Subnet mask >** and **< Gw Address >** menus and repeat the same steps to configure the subnet and gateway addresses.

4. When done configuring the IP address press **Left** or **Right** to get to the **< Save Changes? >** menu, then press **Down** and select **< YES >** and then **Down** again to save the base configuration. When the configuration is stored you will be moved back to the **< Setup >** menu. Press **Left** or **Right** to step through the menu until you get to **< Start System >**. Press **Down** twice to start the system.

5. System Running will appear on the display when the SG4200 Series device has started:



```
System Running
```

3.4. Finalizing the Configuration

After initial setup, the user should refer to the companion publications found in PDF format on the accompanying CD for information on how to begin to configure the SG4200 Series device:

**Clavister CorePlus
Administrators Guide**

This describes the general operation and control of the CorePlus firmware, which is the Clavister proprietary operating system that drives and controls the Clavister SG4200 Series hardware. The document includes examples of how to carry out typical administrative tasks such as setting up a VPN, and how to use the SG4200 Series in various scenarios.

**Clavister FineTune
Administrators Guide**

FineTune is a software tool that provides the principal management interface for the SG4200 Series device. The software runs on a Windows based PC workstation and is used by the administrator to manage one or multiple Clavister Security Gateways. This describes how to register your Clavister license and set-up a first security policy.

**Clavister CorePlus Log
Reference Guide**

This documents and describes all log messages that might be generated by CorePlus during operation of the system.



Tip

All current publications can also be downloaded directly in PDF format from from <http://www.clavister.com>.

Chapter 4. Product Maintenance

- Replacing the Power Supply, page 23
- Replacing Fan Modules, page 25

The SG4200 Series device allows the on-site replacement of both fan and power supply modules.

Figure 4.1. Replaceable modules in an SG4200 Series device.



4.1. Replacing the Power Supply

SG4200 Series power supplies

In the SG4200 Series there is a single power supply unit. If the supply fails then the SG4200 Series device will not function. The power supply can be changed on-site through a simple procedure if a back-up power supply is available.

Swapping a Power Supply

To swap a failed power supply:

- Switch off the supply using the power switch at the back of the unit.
- Remove the power supply cord.
- Unscrew the retaining screw to the left of the power supply.
- Gently pull out the failed supply by firmly grasping the pivoted handle at the back of the unit.
- Gently insert the new supply, replace the retaining screw and re-insert the power cord into the new unit.
- Switch on the new unit by using the power-on switch at the back of the unit.
- The green light at the back will illuminate indicating normal operation.

Figure 4.2. Replacing a SG4200 Series power supply.



Figure 4.3. An SG4200 Series AC power supply unit.



Figure 4.4. An SG4200 Series DC power supply unit.



4.2. Replacing Fan Modules

Recommended Replacement Interval

The fan module in a SG4200 Series device is liable to wear from mechanical movement and fan failure can lead to much more serious failures from overheating of electronic components. Although the fan modules are built for prolonged use it is nonetheless a recommended precaution that the fan module (shown below) be replaced every two years.


Figure 4.5. An SG4200 Series fan module.



Replacement Steps

- Power off the SG4200 Series device.
- Unscrew the fan module retaining screws
- Pull the fan module outwards while holding the retaining screws (see below).
- Replace with the new module, securing with the retaining screws.

Figure 4.6. Clavister SG4200 Series fan disassembly.



Chapter 5. Warranty

Limited Warranty

Clavister warrants to the customer of the SG4200 Series Appliance that the Hardware components will be free from defects in material and workmanship under normal use for a period of two (2) years from the Start Date (as defined below). The warranty will only apply to failure of the product if Clavister is informed of the failure not later than two (2) years from the "Start Date" or thirty (30) days after that the failure was or ought to have been noticed by the customer. The warranty will not apply to products from which serial numbers have been removed or to defects resulting from unauthorized modification, operation or storage outside the environmental specifications for the product, in-transit damage, improper maintenance, defects resulting from use of third-party software, accessories, media, supplies, consumables or such items not designed for use with the product, or any other misuse. Any replacement Hardware will be warranted for the remainder of the original warranty period or thirty days, whichever is longer.

Note that the term *Start Date* means the earlier of Product registration or ninety (90) days following shipment from Clavister.

Obtaining Warranty Service

Warranty service may be obtained by contacting Clavister within the applicable warranty period, and requesting a Return Material Authorization (RMA) number. If the product in question has not been registered with the Clavister client web pages, then a proof of purchase (such as a copy of the dated purchase invoice) must be provided. If Purchaser's circumstances require special handling of warranty correction, then at the time of requesting the RMA number, the Purchaser may also propose special procedures as may be suitable to the case.

After an RMA number is issued, the defective product must be packaged securely in the original or other suitable shipping package to ensure that it will not be damaged in transit, and the RMA number must be clearly marked on the outside of the package. The package must be mailed or otherwise shipped to Clavister with all costs of mailing/shipping/insurance prepaid. Clavister shall not be responsible for any of the Purchaser's software, firmware, information, or memory data contained in, stored on, or integrated with any product returned to Clavister pursuant to this warranty.

Any package returned to Clavister without an RMA number will be rejected and shipped back to the Purchaser at the Purchaser's expense. Clavister reserves the right in such a case to levy a reasonable handling charge in addition to mailing and or shipping costs.

To issue an Return Material Authorization (RMA) request for warranty or maintenance service for any Clavister appliance product, please fill out the Clavister RMA request form which can be found and submitted online at (clickable link):

http://www.clavister.com/support/support_rma_request.html

Should there be a problem with the online form then Clavister support can be contacted by email at: **<mailto:support@Clavister.com>**.

The mail address is:
Clavister AB
Torggatan 10
891 27 ÖRNSKÖLDSVIK
SWEDEN

Details of the software procedures to follow when installing new hardware can be found in the FineTune guide.

Customer Remedies

Clavister's entire liability according to this warranty shall be, at Clavister's option, either return of the price paid, or repair or replacement of the Hardware that does not meet Clavister's limited warranty and which is returned to Clavister with a copy of your receipt.

Limitations of Liability

Refer to the legal statement at the beginning of the guide for a statement of liability limitations.

Chapter 6. Safety

Safety Information

Clavister SG4200 Series devices are safety class I products and have protective ground terminals. There must be an uninterrupted safety earth ground from the main power source to the product's input wiring terminals, power cord, or supplied power cord set. Whenever it is likely that the protection has been impaired, disconnect the power cord until the ground has been restored.

For LAN cable grounding:

- If your LAN covers an area served by more than one power distribution system, be sure their safety grounds are securely interconnected.
- LAN cables may occasionally be subject to hazardous transient voltage (such as lightning or disturbances in the electrical utilities power grid). Handle exposed metal components of the network with caution.

There are no user-serviceable parts inside these products. Only service-trained personnel can perform any adjustment, maintenance or repair.

Säkerhetsföreskrifter

Dessa produkter är säkerhetsklassade enligt klass I och har anslutningar för skyddsjord. En obruten skyddsjord måste finnas från strömkällan till produktens nätkabelanslutning eller nätkabel. Om det finns skäl att tro att skyddsjorden har blivit skadad, måste produkten stängas av och nätkabeln avlägnas till dess att skyddsjorden har återställts.

För LAN-kablage gäller dessutom att:

- om LAN:et täcker ett område som betjänas av mer än ett strömförsörjningssystem måste deras respektive skyddsjord vara ihopkopplade.
- LAN kablage kan vara föremål för farliga spänningstransienter (såsom blixtnedslag eller störningar i elnätet). Hantera metallkomponenter i förbindelse med nätverket med försiktighet.

Det finns inga delar i produkten som kan lagas av användaren. All service samt alla justeringar, underhåll eller reparationer får endast utföras av behörig personal.

Informations concernant la sécurité

Cet appareil est un produit de classe I et possède une borne de mise à la terre. La source d'alimentation principale doit être munie d'une prise de terre de sécurité installée aux bornes du câblage d'entrée, sur le cordon d'alimentation ou le cordon de raccordement fourni avec le produit. Lorsque cette protection semble avoir été endommagée, débrancher le cordon d'alimentation jusqu'à ce que la mise à la terre ait été réparée.

Mise à la terre du câble de réseau local:

- si votre réseau local s'étend sur une zone desservie par plus d'un système de distribution de puissance, assurez-vous que les prises de terre de sécurité soient convenablement interconnectées.
- Les câbles de réseaux locaux peuvent occasionnellement être soumis à des surtensions transitoires dangereuses (telles que la foudre ou des perturbations dans le réseau d'alimentation public). Manipulez les composants métalliques du réseau avec précautions.

Aucune pièce contenue à l'intérieur de ce produit ne peut être réparée par l'utilisateur. Tout

dépannage, réglage, entretien ou réparation devra être confié exclusivement à un personnel qualifié.

Hinweise zur Sicherheit

Dies ist ein Gerät der Sicherheitsklasse I und verfügt über einen schützenden Erdungsterminal. Der Betrieb des Geräts erfordert eine ununterbrochene Sicherheitserdung von der Hauptstromquelle zu den Geräteingabeterminals, den Netzkabeln oder dem mit Strom belieferten Netzkabelsatz voraus. Sobald Grund zur Annahme besteht, dass der Schutz beeinträchtigt worden ist, das Netzkabel aus der Wandsteckdose herausziehen, bis die Erdung wiederhergestellt ist.

Für LAN-Kabelerdung:

- Wenn Ihr LAN ein Gebiet umfasst, das von mehr als einem Stromverteilungssystem beliefert wird, müssen Sie sich vergewissern, dass die Sicherheitserdungen fest untereinander verbunden sind.
- LAN-Kabel können gelegentlich gefährlichen Übergangsspannungen ausgesetzt werden (beispielsweise durch Blitz oder Störungen in dem Starkstromnetz des Elektrizitätswerks). Bei der Handhabung exponierter Metallbestandteile des Netzwerkes Vorsicht walten lassen.

Dieses Gerät enthält innen keine durch den Benutzer zu wartenden Teile. Wartungs-, Anpassungs-, Instandhaltungs- oder Reparaturarbeiten dürfen nur von geschultem Bedienungspersonal durchgeführt werden.

Considerazioni sulla sicurezza

Questo prodotto è omologato nella classe di sicurezza I ed ha un terminale protettivo di collegamento a terra. Dev'essere installato un collegamento a terra di sicurezza, non interrompibile che vada dalla fonte d'alimentazione principale ai terminali d'entrata, al cavo d'alimentazione oppure al set cavo d'alimentazione fornito con il prodotto. Ogniqualvolta vi sia probabilità di danneggiamento della protezione, disinserite il cavo d'alimentazione fino a quando il collegamento a terra non sia stato ripristinato.

Per la messa a terra dei cavi LAN:

- se la vostra LAN copre un'area servita da più di un sistema di distribuzione elettrica, accertatevi che i collegamenti a terra di sicurezza siano ben collegati fra loro;
- i cavi LAN possono occasionalmente andare soggetti a pericolose tensioni transitorie (ad esempio, provocate da lampi o disturbi nella griglia d'alimentazione della società elettrica); siate cauti nel toccare parti esposte in metallo della rete.

Nessun componente di questo prodotto può essere riparato dall'utente. Qualsiasi lavoro di riparazione, messa a punto, manutenzione o assistenza va effettuato esclusivamente da personale specializzato.

Consideraciones sobre seguridad

Este aparato se enmarca dentro de la clase I de seguridad y se encuentra protegido por una borna de puesta a tierra. Es preciso que exista una puesta a tierra continua desde la toma de alimentación eléctrica hasta las bornas de los cables de entrada del aparato, el cable de alimentación hasta haberse subsanado el problema.

Puesta a tierra del cable de la red local (LAN):

- Si la LAN abarca un área cuyo suministro eléctrico proviene de más de una red de distribución de electricidad, cerciorarse de que las puestas a tierra estén conectadas entre sí de modo seguro.
- Es posible que los cables de la LAN se vean sometidos de vez en cuando a voltajes

momentáneos que entrañen peligro (rayos o alteraciones en la red de energía eléctrica). Manejar con precaución los componentes de metal de la LAN que estén al descubierto.

Este aparato no contiene pieza alguna susceptible de reparación por parte del usuario. Todas las reparaciones, ajustes o servicio de mantenimiento debe realizarlos solamente el técnico.

Chapter 7. Hardware Specifications



Below are the key hardware specifications for Clavister SG4200 Series installation.

Figure 7.1. SG4200 Series Dimensions and Weight

Height x Width x Depth (mm)	44 x 440 x 440
Device weight	7.0 kg
Device form Factor	1U
Rack Mountable 19" ?	Yes
Power Supply (AC)	100-240V 50 to 60 Hz AC
Power Supply (DC)	36VDC to 72VDC

Figure 7.2. Regulatory and Safety Standards

Safety	UL, CE
EMC	FCC class A, CE class A, VCCI class A

Figure 7.3. Environmental

Humidity	20% to 95% noncondensing
Operational Temperature	5 to 55° C
Vibration	0.41 Grms ² (3-500 Hz)
Shock	30 G

Figure 7.4. Power Specifications

Typical Consumption (W)	90 W
Typical Current @ 230V	400 mA
Typical Current @ 110V	800 mA
BTU	308 BTU
PSU Rated Power (W)	230 W

Further information

For complete product specifications refer to (clickable link):

<http://www.clavister.com/products/>